

Steering Angle Sensor Centering

The steering angle sensor does not require a centering often. Centering of the steering angle sensor might be required after certain service procedures are performed. Some of these procedures are as follows:

- Wheel alignment
- Steering gear replacement
- Steering column replacement
- Steering angle sensor replacement
- Collision or other physical damage
- Electronic brake control module replacement

The steering angle sensor centering procedure can be completed with a scan tool using the following steps:

1. Using the steering wheel, align the front wheels forward.
2. Apply the parking brake, or set the transmission in the Park.
3. Install the scan tool to the data link connector.
4. Ignition ON, engine OFF
5. Select Steering Wheel Angle Sensor Reset in the Steering Wheel Angle Sensor Module Configuration/Reset Functions list.
6. Follow the scan tool directions to complete the reset procedure.
7. Select Steering Wheel Angle Sensor Learn in the Steering Wheel Angle Sensor Module Configuration/Reset Functions list.
8. Follow the scan tool directions to complete the learn procedure.
9. Select Steering Wheel Angle Sensor Learn in the Electronic Brake Control Module Configuration/Reset Functions list.
10. Follow the scan tool directions to complete the Learn procedure.
11. Clear any DTCs that may be set.